


FEATURES



CONTROL FUNCTIONS

Display Panel

Brew Button

Starts brew cycle. Brewing stops automatically or by pressing the brew button again.

Status Light

Green (steady) – wait mode

Red (steady) – brew mode

Red (slow blinking) – carafe or mug not detected

Red (fast blinking) – no water

Adjustable Cup Selector

Selects the amount of water to be used during brew cycle: 2 cup (8 - 10 oz), 4 cup (17 - 19 oz).

Clock

Continuously displays current time and is used for setting automatic brew time.

PM Indicator

Indicates PM for clock.

Beeper On/Off Indicator Light

Indicates if brew complete beeper is on or off.

Auto Timer Switch & Indicator Light

Turns on automatic brew cycle at set time.

Accent Lighting Button

Turns on and off accent lighting located behind brew basket.

PROGRAM DISPLAY PANEL

