

DOCK-MATE SYSTEMS WITH CONTROL VALVES

QUICK-START INSTRUCTIONS

YACHT-MATE™ PRODUCTS IS PROVIDING YOU WITH THE QUICK START-UP INSTRUCTIONS FOR YOUR SYSTEM, AS A GENERAL GUIDE TOWARDS YOUR INITIAL START-UP OR RE-START OF A SYSTEM THAT MAY HAVE BEEN OUT OF SEASONAL SERVICE. IT IS STRONGLY RECOMMENDED THAT YOU READ THE COMPLETE OWNERS MANUAL PRIOR TO PLACING THE SYSTEM IN OPERATION

1. **PRE-FILTER: (WHERE APPLICABLE)**

FILTERS ARE 5 MICRON, PLEATED POLYESTER AND TO REMOVE SEDIMENT, DIRT & RUST PARTICLES. INSTALL THESE FILTERS BEFORE THE SYSTEM (TAKE NOTICE OF THE IN/OUT)

NOTE: YACHT-MATE™ DOES NOT RECOMMEND CARBON FILTERS PRIOR TO FILLING FRESH WATER SYSTEM. WE RECOMMEND TO KEEP WHAT EVER DISINFECTION PROVIDED BY CITY WATER SUPPLIES IN IT AND REMOVE AFTER YOUR TANKS. ALSO BY ADDING A CAP FULL OF BLEACH WILL ASSIST IN KEEPING YOUR FRESH WATER FRESH AS THE WATER TANKS TYPICALLY GET A BIOFILM BUILDUP ADDING A CAP OF BLEACH TO MAINTAIN YOUR TANK WILL HELP KEEP IT UNDER CONTROL ANY EXCESS OF BLEACH WILL SURFACE AND GAS OFF YOUR TANK IS ATMOSPHERIC WE RECOMMEND INSTALLING A UV STERILIZER AFTER THE FRESH WATER PUMPS AND OUR GALLEY-MATE R/O OR A FILTRATION SYSTEM FOR DRINKING, COOKING AND ICE PRODUCTION AT POINT OF USE.

2. **CONNECTION DM-SERIES PORTABLE**

- CONNECT 4 FT HOSE SUPPLIED TO THE WATER SUPPLY & INLET OF SYSTEM ON RIGHT SIDE OF VALVE & YOUR HOSE TO THE OUTLET AFTER THE METER
- LEAVE OUTLET HOSE GUN IN “OFF” OR CLOSED POSITION
- PLACE DRAIN TUBE ON THE ELBOW NEXT TO THE OUTLET AND HANG OVER DOCK TO DISCHARGE
- **IMPORTANT** ATTACH BRINE CONNECTION & CHECK BALL IF NOT ALREADY ATTACHED LOCATED NEXT TO INLET
THIS IS A GREY & BLUE HANDLE VALVE W/ BLACK ELBOW ASSEMBLY & CHECK BALL IN SEPARATE BAG WITH INSTRUCTIONS (IF NOT ALREADY ATTACHED)
- TURN WATER SUPPLY ON **SLOWLY**
- TWIST TIMER CONTROL PAST THE 45 MINUTE MARK—THE SYSTEM WILL FILL IN BACKWASH POSITION, ALLOWING AIR & COLOR TO PURGE FROM UNIT. AFTER 5 MIN. USE SPARY GUN TO HELP WITH PROCESSOPENING AND CLOSING. (TWIST TIMER OFF & ON TO RELIEVE AIR POCKETS) THIS MAY TAKE 10-15 MIN. CHECK DRAIN LINE UNTIL CLEAR
- TWIST TIMER BACK TO 0 MINUTES
- SYSTEM IS READY FOR USE

3. **SYSTEM IS IN SERVICE**

- YOU MAY NOW USE THE SYSTEM FOR WASH-DOWN AND OR FRESH WATER TANK FILLS.
- CHECK THE HARDNESS OF THE UNTREATED WATER SUPPLY WITH TEST KIT SUPPLIED. REFILLS ARE AVAILABLE
- PERIODICALLY CHECK THE DIGITAL METER (WHERE APPLICABLE) TO KNOW WHEN TO RECHARGE, FACE METER OUT OF SUN WHEN POSSIBLE TO PROTECT DISPLAY.

*MODELS: DM1000- 40”H INSTALLED / DM1001-23”UPRIGHT PORTABLE
DM 1004 28” UPRIGHT PORTABLE/ DM1002-DOCK BOX / DM1003 UPRIGHT 20”*

NOTE: UNITS NOT INSTALLED ON BOARD VESSEL SHOULD BE SECURED TO DOCK PILING OR PEDASTAL TO PREVENT PULLING INTO WATER WHEN STRETCHING YOUR HOSE

FOR ASSISTANCE CONTACT YOUR DISTRIBUTOR
OR CALL 1-877-YACHTMATE (922-4862)
954-527-0112 OFFICE