

DOCK-MATE SYSTEMS IN/OUT HEAD DM-1003 QUICK-START INSTRUCTIONS

YACHT-MATE™ PRODUCTS IS PROVIDING YOU WITH THE QUICK START-UP INSTRUCTIONS FOR YOUR SYSTEM, AS A GENERAL GUIDE TOWARDS YOUR INITIAL START-UP OR RE-START OF A SYSTEM THAT MAY HAVE BEEN OUT OF SEASONAL SERVICE. IT IS STRONGLY RECOMMENDED THAT YOU READ THE COMPLETE OWNERS MANUAL PRIOR TO PLACING THE SYSTEM IN OPERATION

1. **PRE-FILTER: (WHERE APPLICABLE)**

FILTERS ARE 5 MICRON, PLEATED POLYESTER AND TO REMOVE SEDIMENT, DIRT & RUST PARTICLES. INSTALL THESE FILTERS BEFORE THE SYSTEM (TAKE NOTICE OF THE IN/OUT)

NOTE: YACHT-MATE™ DOES NOT RECOMMEND CARBON FILTERS PRIOR TO FILLING FRESH WATER SYSTEM. WE RECOMMEND TO KEEP WHAT EVER DISINFECTION PROVIDED BY CITY WATER SUPPLIES IN IT AND REMOVE AFTER YOUR TANKS. ALSO BY ADDING A CAP FULL OF BLEACH WILL ASSIST IN KEEPING YOUR FRESH WATER FRESH AS THE WATER TANKS TYPICALLY GET A BIOFILM BUILDUP ADDING A CAP OF BLEACH TO MAINTAIN YOUR TANK WILL HELP KEEP IT UNDER CONTROL ANY EXCESS OF BLEACH WILL SURFACE AND GAS OFF YOUR TANK IS ATMOSPHERIC WE RECOMMEND TO INSTALL A UV STERILIZER AFTER THE FRESH WATER PUMPS AND OUR GALLEY-MATE R/O OR A FILTRATION SYSTEM FOR DRINKING, COOKING AND ICE PRODUCTION AT POINT OF USE.

2. **CONNECTION**

DM-SERIES PORTABLE

- CONNECT METER TO SPIGOT THEN ATTACH 4 FT HOSE SUPPLIED TO THE WATER SUPPLY & INLET OF SYSTEM
- TURN WATER SUPPLY ON **SLOWLY**
- ALLOWING AIR & COLOR TO PURGE FROM UNIT USE SPARY GUN TO HELP WITH PURGING ONCE WATER IS CLEAR AND AIR IS OUT
- SYSTEM IS READY FOR USE

3. **SYSTEM IS IN SERVICE**

- YOU MAY NOW USE THE SYSTEM FOR WASH-DOWN AND OR FRESH WATER TANK FILLS.
- CHECK THE HARDNESS OF THE UNTREATED WATER SUPPLY WITH TEST KIT SUPPLIED. REFILLS ARE AVAILABLE

*MODELS: DM1000- 40”H INSTALLED / DM1001-23”UPRIGHT PORTABLE
DM 1004 28” UPRIGHT PORTABLE/ DM1002-DOCK BOX / DM1003 UPRIGHT 20”*

NOTE: UNITS NOT INSTALLED ON BOARD VESSEL SHOULD BE SECURED TO DOCK PILING OR PEDASTAL TO PREVENT PULLING INTO WATER WHEN STRETCHING YOUR HOSE

FOR ASSISTANCE CONTACT YOUR DISTRIBUTOR
OR CALL 1-877-YACHTMATE (922-4862)
954-527-0112 OFFICE